

# User guidelines

## litter bins

### Round Heritage Range




**Cleaning** Products should be flushed with clean water and then washed with a mild detergent solution using a bristle brush or sponge. Care should be taken not to apply undue pressure that may damage labels. Flush clean with water after washing.



**Manufacturing Standard** (as applicable)  
 All products are manufactured to BS EN ISO 9002.  
 Plastic materials: Mechanical properties tested to BS 2782 Hot dipped galvanized: BS 729  
 Powder coating: BS 3900 Zinc coating: BS 1706



**Tools Key:**



**PPE** Always wear appropriate PPE equipment and follow safety guidelines

### Unlocking and removing hood



1 Insert key and turn clockwise until stop. Lock will pop out and release



2 Gripping bin apertures twist hood anticlockwise until stop



3 Lift the hood upwards clearing the bin liner, place on ground

Round heritage litter bins can be supplied with either plastic or metal liners

## Removing and replacing liner



4 Grip liner using the two handles



5 Lift liner upwards clearing the bin base and empty



6 Using handles to grip replace liner

## Replacing hood and locking



7 Replace hood and twist clockwise until it drops to its lowest point on base



8 Continue to twist hood clockwise until it will rotate no further



9 Push lock in to engage

## Open top heritage



1 The open top round heritage connects and releases from the base in the same way as the Round heritage



2 Lift hood using rim to grip. Remove and replace liner as with round heritage